



floorcare system

SanoVerde®

No Strip Promise*

*3 year minimum

The **Bullen Companies Inc.** is pleased to introduce the next level in green, sustainable resilient floor maintenance with their new **SanoVerde® floorcare system**. **SanoVerde®** is a Spanish phrase meaning Healthy & Green. This philosophy of “Healthy & Green” guides Bullen’s choice of ingredients, formulations and how best to apply **SanoVerde®** products in a safe and sustainable manner. The **SanoVerde® floorcare system**, which is comprised of five green certified products, is designed to give end-users a three year minimum, no strip floor that will save money on labor and chemical costs....this is the **SanoVerde® floorcare system No Strip Promise***.

The **SanoVerde® floorcare system** products, which are DfE recognized (*U.S. EPA’s Design for the Environment Program*) include a Floor Finish, a Floor Cleaner, a Floor Restorer (Gel or Liquid) and a Deep Scrub & Stripper. These products were developed to work together synergistically to achieve a three year minimum no strip result. **SanoVerde® Floor Finish** is a zinc free interlock polymer coating that dries to a deep gloss and is extremely durable under heavy traffic. When used with **SanoVerde® Floor Restorer** (Gel or Liquid), the finish is easily repaired, cleaned and restored to a brilliant gloss. When used with companion products, **SanoVerde® Deep Scrub & Stripper** and **Floor Cleaner**, end-users can be assured that their floor care maintenance program will produce a safe, clean, glossy floor surface that is durable, will save money, and is compatible with the environment.

To obtain the desired results of the **SanoVerde® floorcare system No-Strip Promise***, the following steps must be implemented:

- Strip all existing finish off the floors.
- Apply five coats of **SanoVerde® Floor Finish** – flat microfiber mop application is strongly recommended.
- Within the first week:
 - Dust mop daily.
 - Clean floor with **SanoVerde® Floor Cleaner** at the use directions on the product label.
 - Burnish the floor after 6-7 days with **SanoVerde® Floor Restorer** (Gel or Liquid) following the procedure on the product label.
- Thereafter, 1) clean floors with **SanoVerde® Floor Cleaner** and 2) burnish floors with **SanoVerde® Floor Restorer** (Gel or Liquid) according to your standard procedures.
- Light to moderate traffic^a: At the end of 6 months, scrub with **SanoVerde® Deep Scrub & Stripper** and recoat by applying two (2) coats of **SanoVerde® Floor Finish**.
- Heavy traffic^b: At the end of 4 months, scrub with **SanoVerde® Deep Scrub & Stripper** and recoat by applying three (3) coats of **SanoVerde® Floor Finish**.
- High speed burnishing equipment must be used on floor.
- The facility must have walk-off mats at all entrances.

^a light to moderate foot traffic <1000 people daily; ^b heavy traffic foot > 1000 people daily